## RJ45 RS485 Sensor Expander ENVIROMUX®

## RJ45 RS485 Sensor Port Hub for E-16D

- Adds eight RJ45 RS485 sensors to the E-16D.
  - Each E-16D supports up to three E-RJ8-RS485 allowing for a total of 37 RJ45 RS485 sensors to be connected to the E-16D.
  - When cascading E-16D units together, only the master unit supports E-RJ8-RS485.
  - Powered by 12VDC 2.5A external power supply (included).
- Compatible with E-16D only.
  - Interfaces with the E-16D via RJ45 Sensor Ports #1, 2, and 3.
  - Note: Sensors connected to the E-RJ8-RS485 are not visible using SNMP or E-MNG management software.
- Supports CAT5/5e/6 cable up to 1000 feet (305 m) between E-16D and the hub.
  - Sensor cable lengths connected to the hub are as specified per sensor.
- Available options: desktop unit with wall mounting brackets, DIN mount unit, 1RU rackmount unit.
- Dimensions WxDxH: 6.82x3x1.72 in (173x76x44 mm)
- Regulatory approvals: CE, RoHS
- Operating temperature: 32 to 158°F (0 to 70°C)
- Storage temperature: -4 to 158°F (0 to 70°C)
- Compatible with E-FSC Fiber Converter/Extender.
- Use to extend sensor up to 1.2 miles (2 km) from the ENVIROMUX unit.



E-RJ8-RS485

Compatible RJ45 RS485 Sensors		
NTI Part #	Description	
E-ACDCLM	AC & DC Voltage & Current Monitor	
E-ACLM-3P480	3-Phase AC Power Monitor	
E-ACLM-P-xx	AC Power Monitors with Relay	
E-ACLM-V	AC Dual Voltage Monitor	
E-ALDS	Addressable Leak Detection Sensor	
E-DCLM-6	DC Line Monitor	
E-DI16DO16	Digital Input/Output Expander (Open-Collector Outputs)	
E-DI16DOR16	Digital Input/Output Expander (Normally-Open Relay Contact Outputs)	
E-S420MA-24V	4-20mA Sensor Converter	
E-S5VDC	5VDC Sensor Converter	
E-S60VDC	DC Voltage Monitor	
E-STHSB	Temperature/Humidity/Dew Point Sensor	
E-STHS-LCDW	Temperature/Humidity Sensor with 3-Digit 7-Segment LCD Display	
E-STHSM-E7	Probe-Style Temperature/Humidity/Dew Point Sensor	
E-STS	Temperature Sensor	
E-STS-O	IP65 Outdoor Temperature Sensor	
E-STSP-7	Pipe Temperature Sensor	
E-STSP-SL-7	Strap-On Pipe Temperature Sensor, Spring-Loaded	

RJ45 RS485 Sensor Port Hub for E-16D		
NTI Part #	Description	
E-RJ8-RS485	8-port RJ45 RS485 Sensor Expander for E-16D	
E-RJ8-RS485-D	8-port RJ45 RS485 Sensor Expander for E-16D, Din Mount	
E-RJ8-RS485-R	8-port RJ45 RS485 Sensor Expander for E-16D, 1RU Rackmount	



1.800.RGB.TECH (800.742.8324) 33 Toll Free: US & Canada In © 2020 NTI.

324) 330.562.7070 a d a International calls © 2020 NTI. All rights reserved. 330.562.1999 Worldwide fax